

## GREEN CELL BATERIE PRO FUJITSU 4400MAH



Cena celkem:	<b>1 071 Kč</b> <b>(bez DPH: 885 Kč)</b>
Kód zboží:	BATRX4600
Part No.:	GCFS07
Záruka:	24 měsíců/6 měs. akku
Stav:	Nové zboží

## Popis

### Green Cell baterie pro Fujitsu 4400 mAh

Kompatibilní baterie **pro notebooky Fujitsu LifeBook**. Baterie je standardně vybavena ochranou proti přetížení, hlubokému vybití a přebití.

### ZÁKLADNÍ SPECIFIKACE

**Kapacita:** 4400 mAh

**Napětí:** 11,1 V (10,8 V)

**Technologie baterie:** Li-ion

### Nahrazuje baterie:

CP293550-01, CP293530-01, CP556150-01, CP556150-02

FMVNBP146, FMVNBP177, FMVNBP178, FPCBP145, FPCBP145AP, FPCBP146, FPCBP218, FPCBP218AP, FPCBP219, FPCBP219AP, FPCBP220, FPCBP220AP, FPCBP238, FPCBP238AP

S26391-F795-L300, S26391-F795-L400, S26391-F956-L100, S26391-F956-L200, S26391-F974-L50

FMVNBP190, FMVNBP198, FMVNBP199, FMVNBP210, FMVNBP242, FMVNGS7H6, FMVNGS7H8, FMVNGS7HE, FMVNS7H6, FMVNS7H6R, FMVNS7H6R2, FMVNS7H7, FMVNS7H7R, FMVNS7H7R2, FMVNS7H8, FMVNS7H8R2, FMVNS7HE, FMVNS7HER, FMVNS7HER2, FMVNS7HEZ, FMVNS7S6, FMVNS7S7, FMVNS7S8, FMVNS7SE, FMVNS7X6, FMVNS7X6R, FMVNS7X6R2, FMVNS7X7, FMVNS7X8, FMVNS7X8R2, FMVNS7XE, FMVNS7XER, FMVNS7XER2, FMVP74EB, FMVP74EN37, FMVP74EN38, FMVP74EW, FMVP75EN37, FMVP75EN38, FMVP75EN57, FMVP75EN58, FMVP75GN37, FMVP75GN38, FMVP75GN57, FMVP75GN58, FMVP75HN37, FMVP75HN38, FMVP75HN57, FMVP75HN58

FMVS54EB, FMVS54EN37, FMVS54EN38, FMVS54EN57, FMVS54EN58, FMVS54ER, FMVS54EW, FMVS54EWG, FMVS54EWTK, FMVS54GB, FMVS54GBG, FMVS54GMG, FMVS54GN37, FMVS54GN38, FMVS54GN57, FMVS54GN58, FMVS54GR, FMVS54GW, FMVS54GWG, FMVS54GWTK, FMVS54HB, FMVS54HN37, FMVS54HN38, FMVS54HN57, FMVS54HN58, FMVS54HR, FMVS54HW, FMVS54JL1R, FMVS54JL1W, FMVS54JL2R, FMVS54JL2W, FMVS54JL3R, FMVS54JL3W, FMVS54KD1R, FMVS54KD1W, FMVS54KD3R, FMVS54KD3W, FMVS54KD4R, FMVS54KD4W, FMVS54KD5R, FMVS54KD5W, FMVS54KD6R, FMVS54KD6W, FMVS54KDBW, FMVS54KDCR, FMVS54KDCW, FMVS54KR, FMVS54KRC, FMVS54KRG, FMVS54KW, FMVS54KWC, FMVS54KWG, FMVS56EBC, FMVS56ERC, FMVS56EWC, FMVS56GBC, FMVS56GRC, FMVS56GWC, FMVS56HBC, FMVS56HRC, FMVS56HWC, FMVS76, FMVS76E, FMVS76G, FMVS76GTK, FMVS76H, FMVS76HTK1, FMVS76HTK2, FMVS7EN5B7, FMVS7EN5B8, FMVS7EN5S7, FMVS7EN5S8, FMVS7EN7B7, FMVS7EN7B8, FMVS7EN7S7, FMVS7EN7S8, FMVS7GN5B7, FMVS7GN5B8, FMVS7GN5S7, FMVS7GN5S8, FMVS7GN7B7, FMVS7GN7B8, FMVS7GN7S7, FMVS7GN7S8, FMVS7HN5B7, FMVS7HN5B8, FMVS7HN5S7, FMVS7HN5S8, FMVS7HN7B7, FMVS7HN7B8, FMVS7HN7S7, FMVS7HN7S8, FPB0262, FPB0333S, FPC02422BK, FPC02424BK, FPC02425BK, FPC02426BK, FPC03481BK, FPC03483BK, FPC03484BK, FPC03485BK, FPC03486BK, FPC04653BK, FPC04654BK, FPC04655DK, FPC04689DK, FPC04689DM, FPC04705BK, FPC04712BK, FPC04719AK, FPC07309BK, FPCBP203, FPCBP281, FPCBP281AP, FPCBP282, FPCBP282AP, FPCBP283, FPCBP283AP, FPCBP325, FPCBP325AP, FPCBP519, MVS54GB

### Pro notebooky:

LifeBook AH52, AH54, AH56, AH572, AH77, AH78

LifeBook A561

LifeBook E741, E751, E752, E782, E8310

LifeBook LH700, LH772, L1010

LifeBook PH701, PH702, P701, P702, P770, P771, P772, P8110

LifeBook SH560, SH561, SH572, SH760, SH761, SH762, SH771, SH772, SH782, SH792

LifeBook S2210, S561, S6310, S6311, S710, S7110, S7111, S751, S752, S760, S761, S762, S782, S792

LifeBook TH550, T580